






3.5 Energy Measurements

Each successive press of the button selects a new range:



Instantaneous Power in kVA.

Instantaneous Volt-Amps in KVA.

Total kW, kVAh, kVA.

Total active energy in kWh.

Total reactive energy in kVAh.

Imported active energy in kWh.

Exported active energy in kWh.

Imported reactive energy in kVAh.

Exported reactive energy in kVAh.

Please note the register is 9999999.9 display over two lines.

4 Setup

To enter set up mode, hold the button for 3 seconds, until the password screen appears.



The setup is password-protected so you must enter the correct password (default '1000') before processing.

If an incorrect password is entered, the display will show: PASS Err (Error).

To exit the set up menu, hold the button for 3 seconds, the measurement screen will display.

4.1 Set up Entry Methods

Some menu items, such as Password and CT, require a four-digit number entry while others, such as supply system, require selection from a number of menu options.

4.1.1 Menu Option Selection

1. Use the and buttons to scroll through the different options of the setup menu.
2. Hold the button for 3 seconds to confirm your selection.
3. If an item flashes, then it can be adjusted by the and buttons.

4. Having selected an option from the current layer, hold the button for 3 seconds to confirm your selection.

5. On completion of setting-up, hold the button for 3 seconds, the measurement screen will then be restored.

4.1.2 Number Entry Procedure


When setting up the unit, some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right. The procedure is as follows:

1. The current digit to be set flashes and then can be adjusted using the and buttons.
2. Press the button to move right to the next digit.
3. After setting the last digit, hold the button for 3 seconds to save your selection.

4.2 Communication

The RS485 port can be used for communication using Modbus RTU Protocol. Configuring the Modbus settings, such as Address and Baud Rate, is also done within the Password-protected setup menu.


4.2.1 RS485 Address



Use the and buttons to select the menu option. The screen will show the current setting.



4.2.2 Baud Rate



4.2.3 Parity



Hold the button to set the meter Address Range: 001(default) to 247.

Use the and buttons to choose the necessary number, then press the button to move along to the next number.

To save the new setting, hold the button for 3 seconds until the selection stops flashing.

Use the and buttons to select the menu option. The screen will show the current setting.

Hold the button to enter the menu option, the current selection will flash.

Use the and buttons to select the required option.



On completion of the entry procedure, hold the button to confirm the setting.

Use the and buttons to select the menu option. The screen will show the current setting.





Hold the button to enter the menu option, the current selection will flash.



4.2.4 Stop bits



4.3 CT Configuration



Use the and buttons to select the required option. Range: None (default), Odd or Even.

On completion of the entry procedure,

hold the button for 3 seconds until the selection stops flashing.

Use the and buttons to select the menu option. The screen will show the current setting.

Hold the button to enter the menu option, the current selection will flash.

Use the and buttons to select the menu option. Range: 1 (default) or 2.

On completion of the entry procedure, hold

the button for 3 seconds until the selection stops flashing.

Use the and buttons to select the CT menu option. The screen will show the current setting.


Secondary CT Setting:

Enter the secondary CT menu by

pressing the button for 3 seconds.

Use the and buttons to select the CT secondary value: 5A (default) or 1A.

Hold the button for 3 seconds to save the selection.




Primary CT Setting:

Enter the primary CT menu by pressing the  button for 3 seconds.

Use the  and  buttons to select the CT value.

Hold the  button for 3 seconds to save the selection.

Press  to exit once complete.



Hold the  button to enter the menu option, the current selection will flash.

Use the  and  buttons to select the required option. Hold the  button to confirm the selection.


Once complete, push the  button to exit the menu.

4.5.1 Pulse Rate
You can configure the number of pulses to relate to a defined amount of Total Energy.

Please note there are limitations that need to be factored in when setting the pulsed output. This is based upon the relay output only being able to pulse 2 times per second.

For example, if the CT is set to 500/5A on a Single Phase network this would generate (500Ax230V=115,000 / 1000) 115kWh which is 31W per second. A setting of 10IMP/kWh (10 pulses per kWh) would generate 3 pulses per second. This will exceed the 2 pulse per second limitation.

Pulse settings: 1 Pulse per: 10W (0.01) / 100W (0.1) /1000W/1kWh (1) / 10kWh (10) / 100kWh (100) /1000kWh (1000)




Use the  and  buttons to select the menu option. The screen will show the current setting.

Hold the  button to enter the menu option, the current selection will flash.

Use the  and  buttons to choose the desired pulse rate.

To save the new setting, hold the  button for 3 seconds to save the setting.


4.5.2 Pulse Duration
The energy monitored can be active or reactive and the pulse width can be selected as 200, 100 or 60ms.



Use the  and  buttons to choose the desired pulse rate.

To save the new setting, hold the  button for 3 seconds.

4.6.1 DIT (Demand Integration Time)
This sets the period (in minutes) in which the Current and Power readings are integrated for maximum demand measurement. The options are 0; 5; 8; 10; 15; 20; 30 or 60 minutes.



Use the  and  buttons to select the menu option. The screen will show the current setting.


Hold the  button to enter the menu option, the current selection will flash.

Use the  and  buttons to select the required option.

Hold the  button to confirm the selection.

Push the  button to exit the menu.

4.6.2 Demand Method
Within this menu, you are able to set whether the demand is displayed using a sliding or fixed method.



Use the  and  buttons to select the menu option. The screen will show the current setting.


Hold the  button to enter the menu option, the current selection will flash.

Use the  and  buttons to select the required option.

Hold the  button to confirm the selection.

Push the  button to exit the menu.

4.7.1 Back Light
The back light is a programmable time (in minutes) that determines how long this remains on for before this goes into standby.



Use the  and  buttons to select the menu option. The screen will show the current setting.


Hold the  button to enter the menu option, the current selection will flash.

Use the  and  buttons to select the required time.

Hold the  button to confirm the selection.

Push the  button to exit the menu.

4.7.2 Display Scroll
Within this menu, you can determine how long the screen is displayed for before it scrolls to the next screen.



Use the  and  buttons to select the menu option. The screen will show the current setting.

Hold the  button to enter the menu option, the current selection will flash.


Use the  and  buttons to select the required option.

Hold the  button to confirm the selection.

Push the  button to exit the menu.

Note: The unit is able to measure from 57.7V AC L-N however PT2 must be set from 100-276V AC L-N.

4.5 Pulsed Output
Use this section to configure the Pulsed Output Type. Units: kVArh (default); kWh.



Use the  and  buttons to select the menu option. The screen will show the current setting.

4.8.1 Supply System

The unit has a default setting of 3 Phase 4 Wire (3P4W).

Use this section to set the type of electrical system.

SEt
SYS

Use the  and  buttons to select the menu option. The screen will show the current setting.

SEt
SYS
tYPE
3P4

Hold the  button to enter the menu option, the current selection will flash.

SYS
3P3

Use the  and  buttons to select the required option.

SYS
3P3

Hold the  button to confirm your adjustment.

Press the  button to exit.

4.8.2 Auto Scroll

Use this menu to determine whether you would like he display to scroll through the various display screens.

SEt
AUtO
di SP
SCRt

Use the  and  buttons to select the menu option. The screen will show the current setting.

AUtO
di SP
SCRt
OFF

Hold the  button to enter the menu option, the current selection will flash.

AUtO
di SP
SCRt
ON

Use the  and  buttons to select the required option.

AUtO
di SP
SCRt
ON

Hold the  button to confirm the selection.

Push the  button to exit the menu.

4.9 Reset

The meter provides a function to reset the maximum demand value of current and power.

SEt
rESEt

Use the  and  buttons to select the menu option. The screen will show the current setting.

SEt
rSEt
ENgY

Hold the  button to enter the menu option, the current selection will flash.

SEt
rSEt
ENgY

Use the  and  buttons to select the option you would like to reset.

SEt
rSEt
ENgY

Hold the  button to reset.

Press  to return to the main menu.

4.10 Change Password

SEt
PASS
yOPd
1000

Use the  and  to choose the change password option.

SEt
PASS
yOPd
1000

Hold the  button to enter the set up menu. The first digit will start flashing.

SEt
PASS
yOPd
1100

Use  and  to set the first digit

and press  to move right. The next digit will flash.

SEt
PASS
yOPd
1100

Repeat the procedure for the remaining three digits.

SEt
PASS
yOPd
1111

After setting the last digit, hold the  button to save your selection.

Hold the  button to exit the menu.

SEt
SYS
CNct

Use the  and  buttons to select the menu option. Hold the  button to view the sub-menu.

SYS
CNct
PH-1
FRd

Within this screen, you can change “Forward” to “Reverse” on each individual CT connection.

SYS
CNct
PH-2
rEV

Hold the  button to confirm your adjustment.

You can then move on to IB or IC using the  and  buttons.

Once complete, hold the  button for 3 seconds to exit the setup menu.

5 Specifications

5.1 Measured Parameters

The unit can monitor and display the following parameters of a Single Phase Two Wire (1P2W), Three Phase Three Wire (3P3W) or Three Phase Four Wire (3P4W) system.

5.1.1 Voltage and Current

- Phase to Neutral Voltages 57.7-276V AC (L-N).
- Phase to Phase Voltages 100-480V AC (L-L).
- Percentage Total Voltage Harmonic Distortion (V %THD) for each Phase to Neutral (not for 3P3W supplies).
- Percentage Total Voltage Harmonic Distortion (V% THD) between Phases (3 Phase supplies only).
- Current %THD for each Phase.
- Burden <15VA (nom 2VA)
- Self powered from any phase

5.1.2 Power factor and Frequency and Max. Demand

- Frequency in Hz
- Instantaneous power:
- Power 0-3600 MW
- Reactive power 0-3600 MVA
- Volt-amps 0-3600 MVA
- Maximum Demand Power since last reset
- Power factor
- Maximum Neutral Demand Current, since the last reset (for 3P4W supplies only)

5.1.3 Energy Measurements

- Imported/Exported active energy 0 to 9999999.9 kWh
- Imported/Exported reactive energy 0 to 9999999.9 kVAh
- Total active energy 0 to 9999999.9 kWh
- Total reactive energy 0 to 9999999.9 kVAh

5.2 Measured Inputs

Voltage inputs through 4-way fixed connector with 2.5mm² stranded wire capacity. Single Phase Two Wire (1P2W), Three Phase Three Wire (3P3W) or Three Phase Four Wire (3P4W) unbalanced. Line frequency measured from L1 Voltage or L3 Voltage. Three current inputs (six physical terminals) with 2.5mm² stranded wire capacity for connection of external CTs. Nominal rated input current 5A or 1A AC RMS.

5.3 Accuracy

- Voltage 0-5% of range maximum
- Current 0-5% of nominal
- Frequency 0-2% of mid-frequency
- Power factor 1% of unity (0.01)
- Active power (W) ±1% of range maximum
- Reactive power (VA) ±1% of range maximum
- Apparent power (VA) ±1% of range maximum
- Active energy (Wh) Class 1 IEC 62053-21
- Reactive energy (VAh) ±1% of range maximum
- Total harmonic distortion 2% up to 63rd harmonic
- Response time to step input 1s, typical, to >99% of final reading, at 50 Hz.

5.4 Auxiliary Supply

This product is self-powered from any of the three phases.

5.5 Interfaces for External Monitoring

Three interfaces are provided:

- RS485 communication channel that can be programmed for Modbus RTU protocol
- Pulse output 1 indicating real-time measured energy (configurable)
- Pulse output 2 3200IMP/kWh (not configurable)

The Modbus configuration (baud rate etc.) and the pulse relay output assignments (kW/kVAh) are configured through the set-up screens.

5.5.1 Pulse Output

Opto-coupler with potential free SPST-NO Contact (Contact rating 5-27V DC / Max current input: Imin 2mA and Imax 27mA DC). The pulse output can be set to generate pulses to represent kWh or kVAh.

Rate can be set to generate 1 pulse per:

- 0.001 = 1 Wh/VAh
- 0.01 = 10 Wh/VAh
- 1 = 1 kWh/kVAh
- 10 = 10 kWh/kVAh
- 100 = 100 kWh/kVAh
- 1000 = 1000 kWh/kVAh

Pulse width 200/100/60 mS.

5.5.2 RS485 Output for Modbus RTU

For Modbus RTU, the following RS485 communication parameters can be configured from the set-up menu:

Baud rate: 2400, 4800, 9600, 19200, 38400

Parity: none (default) / odd / even

Stop bits: 1 or 2

RS485 Network Address: 3 digit number - 001-247

Modbus™ Word order Hi/Lo byte order is set automatically to normal as defined in IEEE 754. It cannot be configured from the set-up menu.

5.6 Reference Conditions of Influence Quantities

Influence Quantities are variables that affect measurement errors to a minor degree. Accuracy is verified under nominal value (within the specified tolerance) of these conditions.

- Ambient temperature 23°C ±1°C
- Input waveform 50 or 60Hz ±2%
- Input waveform Sinusoidal (distortion factor < 0-005)
- Auxiliary supply voltage Nominal ±1%
- Auxiliary supply frequency Nominal ±1%
- Auxiliary supply waveform (if AC) Sinusoidal (distortion factor < 0-05)
- Magnetic field of external origin Terrestrial flux

5.7 Environment

- Operating temperature -25°C to +55°C*
- Storage temperature -40°C to +70°C*
- Relative humidity 0 to 95%, non-condensing
- Altitude Up to 3000m
- Warm up time 1 minute
- Vibration 10Hz to 50Hz, IEC 60068-2-6, 2g
- Shock 30g in 3 planes

*Maximum operating and storage temperatures are in the context of typical daily and seasonal variation.

5.8 Mechanics

- | | |
|---------------------|-----------------------|
| • Enclosure Style | DIN 96 panel mount |
| • Dimensions | 96x96x62 mm |
| • Panel cut-out | 92x92mm |
| • Panel thickness | 1-5 mm |
| • Protection rating | Front IP54, Rear IP30 |
| • Material | UL 94-VO |
| • Weight | 340 g |

6 Installation and Maintenance

6.1 Installation notes

Units should be installed in a dry position, where the ambient temperature is reasonably stable and will not be outside the range -25 to +55°C. Vibration should be kept to a minimum. Preferably, mount the Integra so that the display contrast is not reduced by direct sunlight or other high intensity lighting.

6.2 Input Wiring and Fusing

Voltage lines must be fused with a fast blow AC fuse 1A maximum. Choose fuses of a type and with a breaking capacity appropriate to the supply and in accordance with local regulations. A switch or circuit breaker allowing isolation of supplies to the unit must be provided.

6.3 Wire Size

Voltage and current terminal blocks will accept 0.5mm² to 2.5mm² stranded cable.


6.4 Maintenance

The front of the case should be wiped with a dry cloth only, using minimal pressure. If necessary wipe the rear case with a dry cloth. No user serviceable parts.

7 Declaration of Conformity


We, Tyco Electronics UK Ltd, declare under our sole responsibility as the manufacturer that the poly phase multifunction electrical energy meter “Integra 1222” correspond to the production model described in the EC-type examination certificate and to the requirements of the Directive 2004/22/EC EC type examination certificate number 0120/SGS0251. Identification number of the NB 0120.

8 Dimensions




9 Installation

9.1 Single phase two wires




9.3 Three phase four wires




The maximum number of products that can be connect is a single chain is 20 products.

9.2 Three phase three wires



Please note for 3P3W configuration L2 is connected through the neutral and not V2.

Explanation of Symbols



While TE has made every reasonable effort to ensure the accuracy of the information in this catalogue, TE does not guarantee that it is error-free, nor does TE make any other representation, warranty or guarantee that the information is accurate, correct, reliable or current. TE reserves the right to make any adjustments to the information contained herein at any time without notice. TE expressly disclaims all implied warranties regarding the information contained herein, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose. The dimensions in this catalogue are for reference purposes only and are subject to change without notice. Specifications are subject to change without notice. Consult TE for the latest dimensions and design specifications. TE connectivity (logo), TE (logo) and TE Connectivity are trademarks of the TE Connectivity Ltd. family of companies. Crompton is a trademark of Crompton Parkinson and is used by TE Connectivity under a licence. Other logos, product and company names mentioned herein may be trademarks of their respective owners

TE Energy – innovative and economical solutions for the electrical power industry: cable accessories, connectors & fittings, insulators & insulation, surge arresters, switching equipment, street lighting, power measurement and control.



Authorized Distributor:

WESCHLER INSTRUMENTS

phone: 800-903-9870 440-378-6580

fax: 800-903-9590 440-238-0660

www.weschler.com info@weschler.com

Tyco Electronics UK Ltd

TE Energy

Freebournes Road

Witham, Essex CM8 3AH

Phone: +44 (0)870 870 7500

Fax: +44 (0)870 240 5289

Email: Crompton.info@te.com

www.crompton-instruments.com